



The AR-15/M16 Sight Tools make movement of sight adjustments much easier and quicker than the field method using the point of a bullet. The A1 Sight Tool, designed for the AR-15/M16A1, has five prongs on the end of the small tube that extends down over the Front Sight. These prongs fit the five cuts in the Front Sight Post and at the same time depress the Front Sight Detent.

The A2 Sight Tool can be identified by the *four* prongs on the end of the smaller diameter tube. This tool is for the A2 series AR-15/M16 rifles.

Both A1 and A2 Sight Tools have five prongs on the larger, knurled portion of the tool. These prongs fit the notches in the Windage Drum of the A1 rear sight and depress the detent allowing positive windage adjustments.



### WARNING



Never attempt to disassemble or reassemble a firearm unless you are absolutely certain that it is empty and unloaded. Visually inspect the chamber, the magazine and firing mechanism to be absolutely certain that no ammunition remains in the firearm. Disassembly and reassembly should follow the manufacturer's instructions. If such instructions are not immediately available, contact the manufacturer to see if they are available. If they are not available at all, then you should consult other reference sources such as reference books or persons with sufficient knowledge. If such alternative sources are not available and you have a need to disassemble or reassemble the firearm, you should proceed basing your procedures on common sense and experience with similarly constructed firearms.

With regard to the use of these tools, the advice of Brownells Incorporated is general. If there is any question as to a specific application it would be best to seek out specific advice from other sources and not solely rely on the general advice and warnings given.

### HOW TO USE

Turning the Sight Tool and Front Sight Post in a *clockwise* direction will lower the Front Sight Post, *raising* the bullet's impact on the target. To lower bullet impact on the target, raise the Front Sight Post by turning it *counterclockwise*. To remove the Front Sight Post, turn *counterclockwise* until it unscrews completely.

Turning the Sight Tool and Windage Drum *clockwise* will cause the rear sight to move to the *right* while turning the Windage Drum *counterclockwise* will cause the rear sight to move to the *left*.

**Shop Hint:** When making adjustments to either the front or rear sight while on the range you may have some difficulty "feeling" the detents as you rotate the Sight Tool. To add "feel", remove any two non-adjacent prongs from both ends of the Sight Tool. Position the prongs so the detent is depressed but the holes on either side of the detent do NOT have a prong in them. When the Sight Tool is turned, the detent can engage or slip into the detent recess providing a positive stop.

**Please Note:** The prongs on the A1 and A2 Sight Tools are **very** thin and easily bent or damaged. Use with extreme care; do **not** drop or damage.

# AR-15/M16 A1 & A2 SIGHT TOOLS

READ & FOLLOW THESE  
**INSTRUCTIONS**

## BROWNELLS

SELECTION. SERVICE. SATISFACTION.<sup>®</sup>  
200 S. Front St. Montezuma, IA 50171  
800-741-0015 or 641-623-4000 • [www.brownells.com](http://www.brownells.com)  
World's Largest Supplier of  
Firearms Accessories and Gunsmithing Tools.™