



We recommend the Brownells adjustable extractor star support tool to be used when unscrewing the ejector rod. Stock #080-720-038 for .38/.357 caliber, or #080-720-044 for .44/.45 calipers. This support helps prevent damage to the extractor guide pins and extractor star when unscrewing the ejector rod. **CAUTION:** Ejector rods are easily bent, threads stripped, or sheared off, use caution and unscrew carefully.



### WARNING



Never attempt to disassemble or reassemble a firearm unless you are absolutely certain that it is empty and unloaded. Visually inspect the chamber, the magazine and firing mechanism to be absolutely certain that no ammunition remains in the firearm. Disassembly and reassembly should follow the manufacturer's instructions. If such instructions are not immediately available, contact the manufacturer to see if they are available. If they are not available at all, then you should consult other reference sources such as reference books or persons with sufficient knowledge. If such alternative sources are not available and you have a need to disassemble or reassemble the firearm, you should proceed basing your procedures on common sense and experience with similarly constructed firearms.

With regard to the use of these tools, the advice of Brownells Incorporated is general. If there is any question as to a specific application it would be best to seek out specific advice from other sources and not solely rely on the general advice and warnings given.

### HOW TO USE

With the extractor star properly supported, slide the ejector rod tool down over the ejector rod, as close to the cylinder as possible to prevent bending the rod.

Tighten the clamping screw until the tool is tight on the ejector rod and unscrew by hand.

Do not apply excessive force to unscrew the rod.

Reassemble the firearm according to the manufacturer's instructions. Check for proper functioning using **ACTION PROVING DUMMIES**. Make sure **ALL SAFETY MECHANISMS** are fully functional as designed and approved by the manufacturer. If these tests prove satisfactory, test-fire the firearm with live ammunition in a **SAFE** and **APPROPRIATE** manner. **IMPORTANT!** Start the live ammunition tests by first loading an **ACTION PROVING DUMMY**, then a live round, into the magazine. Only after several tests have been conducted in this manner should additional rounds be placed in the magazine and fired.

# BROWNELLS<sup>®</sup>

## RUGER<sup>®</sup> SECURITY-SIX<sup>®</sup>

### EXTRACTOR

### ROD REMOVAL

### TOOL

#080-000-538



READ & FOLLOW THESE  
INSTRUCTIONS

## BROWNELLS<sup>®</sup>

SELECTION. SERVICE. SATISFACTION.<sup>®</sup>

200 S. Front St. Montezuma, IA 50171  
800-741-0015 or 641-623-4000 • [www.brownells.com](http://www.brownells.com)  
World's Largest Supplier of  
Firearms Accessories and Gunsmithing Tools.<sup>™</sup>