



For most gunsmithing purposes, a hammer with interchangeable, non-marring heads is more suitable than a standard, steel-headed hammer which can dent or deform critical parts.

The Brownells Interchangeable Head Hammers provide the best combination of "hard" and "soft" heads for the working gunsmith. The brass or steel heads provide weight and rigidity, while the nylon, plastic or phenolic head is always readily available for those instances when even softer material is required for more delicate work.



WARNING



Never attempt to disassemble or reassemble a firearm unless you are absolutely certain that it is empty and unloaded. Visually inspect the chamber, the magazine and firing mechanism to be absolutely certain that no ammunition remains in the firearm. Disassembly and reassembly should follow the manufacturer's instructions. If such instructions are not immediately available, contact the manufacturer to see if they are available. If they are not available at all, then you should consult other reference sources such as reference books or persons with sufficient knowledge. If such alternative sources are not available and you have a need to disassemble or reassemble the firearm, you should proceed basing your procedures on common sense and experience with similarly constructed firearms.

With regard to the use of these tools, the advice of Brownells Incorporated is general. If there is any question as to a specific application it would be best to seek out specific advice from other sources and not solely rely on the general advice and warnings given.

HOW TO USE

Whenever any type of gunsmithing work is being done, safety glasses **MUST** be worn. This is especially important when using a hammer to strike other tools or metal parts.

Before using the Brownells Interchangeable Head Hammer, always check the threaded head inserts to make sure they are securely fastened to the hammer. In addition, periodically check the fit of the head to the wooden handle. If it becomes loose, refit the head so it is firmly attached to the handle.

DO NOT USE THIS HAMMER TO DRIVE NAILS OR TACKS! If you are faced with a task such as this, use a standard carpenter's hammer. The heads on this hammer will deform if used for this purpose. Again, **IF YOU MUST DRIVE IN A NAIL OR TACK, USE A STEEL-HEADED, CARPENTER'S HAMMER!**

The heads can be replaced if required. Simply clamp the head to be removed in a vise and turn the handle off the head in a *counter-clockwise* direction. The new head can then be installed by clamping the head in the vise so the threads are accessible and turning the handle onto the head in a *clockwise* direction. When installing the heads (especially the nylon or plastic heads), be very careful that you do not crossthread the head.

BROWNELLS[®]

INTERCHANGEABLE

HEAD

HAMMER

READ & FOLLOW THESE
INSTRUCTIONS

BROWNELLS[®]

SELECTION. SERVICE. SATISFACTION.[®]
200 S. Front St. Montezuma, IA 50171
800-741-0015 or 641-623-4000 • www.brownells.com

World's Largest Supplier of
Firearms Accessories and Gunsmithing Tools.™